



HOBART

**REUSABLE CUP WASHING SOLUTION
FOR UNDERCOUNTER DISHWASHERS**

REUSABLE CUP WASHING: DRY CUPS IN A FLASH

Reusable cups are intended to be used more than once and are thus frequently washed in order to conserve resources and protect the environment. But there are challenges in achieving a completely hygienic result that involve the removal of dried residues from beverages and traces of lipstick, as well as natural sources of soiling such as dust. The cleaning and drying of the cups is further compounded by cup geometry, including recesses, ribs and lips. It is essential that the cup is absolutely dry before you can reuse it or stack it for storage. To achieve an optimal washing and drying result, the right combination of machine, rack system and chemicals is necessary. HOBART has managed to successfully achieve this.

THE SUCCESSFUL CONCEPT:

PREMAX GP / FP with built-in TOP-DRY drying

- + Reusable cup rack for up to 25 cups per wash cycle
- + HYLIN plastic rinse aid HLP-7000



RELIABLE HYGIENE AT ALL TIMES

The combination of a HOBART **PREMAX GP / FP** undercounter dishwasher with built-in TOP-DRY drying, the HOBART **reusable cup rack** and the **HYLINE plastic rinse aid HLP-7000** delivers a perfectly hygienic wash result.

PROCESS RELIABILITY

Washing and drying 25 cups at the same time. In the HOBART reusable cup rack, the cups are simply placed upside down onto the holders and fixed with a special weighted grid. This stops them from moving during the wash cycle.

Thanks to the TOP-DRY drying, there is no need to dry the reusable cups by hand. This saves valuable time.



DRY CUPS

In a small wash up area – where space is already cramped – the reusable cups should ideally be stacked and put away straight after the wash cycle. This was not always possible, however, as the reusable cups needed to be dried by hand first. Now you do not lose any valuable time drying the cups. Thanks to HOBART's successful concept, the reusable cups can be stacked and stored straightaway.

FLEXIBILITY

Not only reusable cups can be washed, but also other wash ware: the **PREMAX GP/ FP** undercounter dishwashers can be switched between these modes in one easy step. Just change the rack and switch on the standard programme with TOP-DRY drying. In a flexible and user-friendly way.

